



Sunroof Rattle

The sunroof rattles, partly because the rear weight is hinged off the front. There's one way to lessen or eliminate it.

Viewed from the rear, there's a small pin sticking sideways off the rear bracket. Raise the rear of the roof. There's not enough room for any size hose, so slide a short piece of heat-shrink tubing on it- doesn't have to be heated. Done.





INDEX